



**Example Company**  
**Example Well Pad Layout**  
 NW1/4 SW1/4, SECTION xx, T x S, R xx W, 6th P.M.



- LEGEND**
- S- = SLASH
  - ST = SEDIMENT TRAP
  - SR = SEDIMENT RESERVOIR
  - R.O.D. = RUN-ON DIVERSION
  - W- = PERIMETER CONTROL (WATTLES)
  - CSD = CUT SLOPE DIVERSION (BERM TOE OF CUT SLOPE)
  - D = FILL DIVERSION TO SEDIMENT TRAP
  - VGB = VEGETATION BUFFER (UNDISTURBED LAND INSIDE PC)
  - FCD = FLOW CONTROL DITCH
  - PARI = PAD/ACCESS ROAD INTERFACE
  - ▨ = LEVEL SPREADER
  - - - = TOE BERM (PLACED AT TOE OF ALL FILL SLOPES/STOCKPILES)
  - - - = TOPSOIL BERM
  - SEED, ECB & FLEX
  - SEED



**WASATCH SURVEYING**  
 906 Main Street  
 Evanston, Wyoming 82930  
 Phone No. (307) 789-4545

<b>Well Pad Layout</b>		<b>Scale: 1" = 60'</b>	<b>SHEET</b>
Project No.	XX-XX-XX	Date Surveyed:	x/xx/xx
Date Drawn:	x/xx/xx	Latest Revision Date:	
			<b>1</b>
			<b>OF 1</b>